

PROTECT YOURSELF FROM THE UNEXPECTED.



EXCLUSIONARY - THE BEST COVERAGE AVAILABLE FOR YOUR VEHICLE **AFFORDABLE, RELIABLE, COMPLETE** Protect Your Ownership Experience.SM

WHAT IS EXCLUSIONARY COVERAGE?

It is the best repair coverage beyond the factory warranty that you can get. PORTFOLIO EXCLUSIONARY covers just about everything. It's easier to list what is **not covered**- *EXCLUDED* - than to list everything that is covered.

WHAT'S EXCLUDED?


Routine maintenance items such as: oil, coolant, fluids, refrigerant and others.

Items that occasionally need replacement such as: battery and cables, lights and bulbs, tires, brake pads, brake drums, brake shoes, exhaust system, shock absorbers, and strut insert cartridges.

Appearance concerns and exterior items such as: bright metal, vinyl, wheel covers, ornaments, and paint.

Interior items such as: upholstery, buttons, carpet, door and window handles.

(This is a summary of exclusions. See your service agreement for a complete list of what is not covered.)



REPAIR COSTS LIKE THESE CAN BE HARD TO BUDGET FOR.*

*Actual costs vary according to year, make, and model, and from state to state. These are representative possible costs from Portfolio data.

See your extended service agreement for all details of coverage, benefits, terms, conditions and exclusions. A printed sample of this extended service agreement is available upon request.

INCLUDES ROADSIDE ASSISTANCE

Roadside Assistance provides towing and other emergency needs. If you have a breakdown or need assistance, all you do is call the toll-free 800 number and a dedicated staff is there to help you 24 hours a day.

TOWING

In the event of a covered mechanical breakdown, towing will be provided to you. No matter where, no matter the time of day. Just call.

GASOLINE AND FLUIDS

An emergency supply of gasoline, oil, cooling fluid & water will be delivered to you when an immediate need arises.

FLAT TIRE ASSISTANCE

Removal and replacement of a flat tire with your spare.

LOCK-OUT

The service will provide for a commercial locksmith to gain entry to your vehicle if the keys are locked in the vehicle.

BATTERY JUMPSTART

If a battery failure occurs, a jumpstart will be delivered to you when in immediate need.

TOLL FREE ACCESS

If you need assistance for any of the above services, just call the toll-free 800 number on your contract.

Your Portfolio service agreement also includes:

SUBSTITUTE TRANSPORTATION for qualified repairs when your vehicle is kept at the repair facility overnight.

TRANSFERABILITY For added resale value your coverage can be transferred to a new owner, should you decide to sell your vehicle.

LIGHT COMMERCIAL USE for your business or employment, if the surcharge is paid

See your extended service agreement for all details of coverage and benefits.

COMPANION COVERAGE PLANS CA or CB

These plans are for the vehicle that has an underlying extended powertrain warranty from the manufacturer. Includes all components covered under either Plan A Stated Component or Plan B Exclusionary Coverage except Powertrain components listed under "Plan P Powertrain Coverage" on reverse side of this deskmat, and items listed under "What Is Not Covered" in the service agreement.

PROTECT YOURSELF FROM THE UNEXPECTED.

STATED COMPONENT COVERAGE

INCLUDES POWERTRAIN COVERAGE PLUS:

ENGINE COOLING SYSTEM

Fan, fan clutch, fan motor.

FACTORY AIR CONDITIONING

Condenser, compressor, clutch and pulley, evaporator, receiver dryer, accumulator, HVAC controller and module, seals and gaskets.

FRONT SUSPENSION

Struts, upper and lower control arms and shafts and bushings; upper and lower ball joints; stabilizer shaft; linkage and bushings; spindles and supports; wheel bearings.

STEERING

All internal lubricated parts; steering gear box, rack and pinion and all internal parts; power cylinder assembly, power steering pump, main and intermediate steering shafts and couplings; tie rods and tie rod ends; linkage; idler arm; pitman arm. Electric steering motor, electric cylinder assembly, rack and pinion with electric power assist.

FUEL SYSTEM

Fuel pump, fuel injection pump, fuel injectors, fuel rail, metal fuel delivery lines, nozzles and vacuum pump and vacuum assist booster.

FACTORY-INSTALLED NAVIGATIONAL SYSTEM

Display, controls, and all electrical components.

BRAKES

Master cylinder; vacuum and hydraulic power brake booster, wheel cylinders; hydraulic lines and fittings; disc calipers.

ELECTRICAL

Alternator, voltage regulator, voltage sensor, distributor, starter motor, starter drive and solenoid; electronic ignition module, wiring harnesses, manually operated switches, wiper motor, power window motor, sunroof motor.


ELECTRONIC HIGH TECH COMPONENTS

Level control compressor, sensors and limiter valve; pneumatic suspension pump, sensors and valves; fuel injection sensors and control module; ignition module; crank sensors; digital or analog instrument cluster; moisture control unit and sensors; anti-detonation sensors; manufacturer installed combination entry system; manufacturer installed anti-theft device; ABS (anti-locking braking system), electronic brake control module.

ELECTRICAL PLUS

All power motors and solenoids related to the electrical operations of antennas, door locks, power headlight motors, seat motors, mirrors, convertible tops, power trunk releases.

The above covered component list is also offered in Plan CA Companion coverage.



REPAIR COSTS LIKE THESE CAN BE HARD TO BUDGET FOR.*

Protect Your Ownership Experience.SM

*Actual costs vary according to year, make, and model, and from state to state. These are representative possible costs from Portfolio data.

INCLUDES ROADSIDE ASSISTANCE

Roadside Assistance provides towing and other emergency needs. If you have a breakdown or need assistance, all you do is call the toll-free 800 number and a dedicated staff is there to help you 24 hours a day.

TOWING

In the event of a covered mechanical breakdown, towing will be provided to you. No matter where, no matter the time of day. Just call.

GASOLINE AND FLUIDS

An emergency supply of gasoline, oil, cooling fluid & water will be delivered to you when an immediate need arises.

FLAT TIRE ASSISTANCE

Removal and replacement of a flat tire with your spare.

LOCK-OUT

The service will provide for a commercial locksmith to gain entry to your vehicle if the keys are locked in the vehicle.

BATTERY JUMPSTART

If a battery failure occurs, a jumpstart will be delivered to you when in immediate need.

TOLL FREE ACCESS

If you need assistance for any of the above services, just call the toll-free 800 number on your contract.

YOUR PORTFOLIO SERVICE AGREEMENT ALSO INCLUDES:

SUBSTITUTE TRANSPORTATION for qualified repairs when your vehicle is kept at the repair facility overnight.

TRANSFERABILITY For added resale value your coverage can be transferred to a new owner, should you decide to sell your vehicle.

LIGHT COMMERCIAL USE for your business or employment, if the surcharge is paid



POWERTRAIN COVERAGE

ENGINE

All internal lubricated parts: bearings, pistons, piston pins and rings, valves, valve springs, valve spring retainers and rocker arms, timing chain or timing belt and tensioners, and rocker arms. Timing gear, oil pump, valve guides, followers, valve seats, rocker shafts, push rods, valve lifters, connecting rods, crankshaft and main bearings, camshaft, cam bearings and rocker bushings. Other parts: Water pump, engine mounts, engine cushions, exhaust manifold, intake manifold, front cover, harmonic balancers, flywheel (flexplate), flywheel ring gear, pulleys and eccentric shaft; seals and gaskets. **Note:** Engine block, cylinder head(s), cylinder sleeves, oil pan and valve covers only if the damage results from the failure of an internal lubricated part. **Turbo/Super Charger:** All internal lubricated parts contained within the turbo/super charger housing, plus the charger housing, only if the damage results from the failure of an internal lubricated part.

TRANSMISSION (AUTOMATIC OR MANUAL)

All internal lubricated parts; torque converter, pump, drums, reaction carrier, shafts, hubs, gears, shift rails and forks, internal linkage, and bearings. Transmission mounts, vacuum modulator; seals and gaskets. The transmission case, housing and oil pan, only if the damage results from the failure of an internal lubricated part.

TRANSFER CASE All internal lubricated parts, plus the transfer case housing only if the damage results from the failure of an internal lubricated part.

DRIVE AXLE ASSEMBLY (FRONT, REAR OR AWD)

All internal lubricated parts contained within the drive axle housing; hub, axle and non-serviceable bearings, drive gears and clutches. Constant velocity joints, universal joints, axle shafts, drive shafts; seals and gaskets. The axle or transaxle housing, only if the damage results from the failure of an internal lubricated part.

See your extended service agreement for all details of coverage, benefits, terms, conditions and exclusions. A printed sample of this extended service agreement is available upon request.